

Date Prepared 11/2004
Prepared By PWatt
Revised _____

BMP CoGen #5

Oil Handling – Transfer to Smaller containers

- Wear proper PPE including safety glasses and cut resistant gloves;
- Ensure spill absorbents are located in immediate vicinity and available during transfer;
- Inspect transfer apparatus (i.e. mechanical hand pump, etc.) for sound mechanical condition;
- Remove container cap/drum bung and position transfer apparatus;
- Utilize and position spill catchment trays or absorbent pads at connection points to prevent spillage during transfer;
-

